



Quick Set-up Guide



Recommended Tools



Included Components



IMPORTANT SAFETY INSTRUCTIONS WARNING

TO REDUCE THE RISK OF SEVERE INJURY OR DEATH, READ AND FOLLOW ALL INSTRUCTIONS.

- 1. NEVER let children operate or play with the door controls.
- 2. Keep remote away from children.
- 3. Locate the wall control button: A) Within sight of door. B) At a minimum height of 5 feet, so small children cannot reach it.
- Install the entrapment WARNING label next to the wall button or console, in a prominent location.
- NO ONE SHOULD CROSS THE PATH OF THE MOVING DOOR.
- 6. NEVER GO UNDER A STOPPED, PARTIALLY OPEN DOOR.
- 7. The Aladdin Connect™ operating system is designed for unattended operation. The door could move unexpectedly.
- DO NOT install Aladdin Connect[™] on garage door openers manufactured prior to 1993 without photocell non-contact safety sensors.
- 9. DO NOT install on one-piece doors
- 10. Install DCM in a location where it can be seen and heard while standing in the door opening with the door in the open position.

SAVE THESE INSTRUCTIONS

CONSIGNES DE SÉCURITÉ IMPORTANTES

AVERTISSEMENT

POUR RÉDUIRE LE RISQUE DE BLESSURES GRAVES VOIRE MORTELLES, LIRE ET COMPRENDRE TOUTES LES INSTRUCTIONS.

- NE JAMAIS laisser les enfants utiliser ou jouer avec les commandes de l'ouvre-porte.
- 2. Tenir les télécommandes hors de la portée des enfants.
- 3. Localiser le bouton de la console murale : A) En vue de la porte. B) À une hauteur minimale de 1,5 m afin que les jeunes enfants ne puissent pas l'atteindre.
- 4. Placer l'étiquette d'AVERTISSEMENT en cas de coinçage à proximité du bouton mural ou de la console murale de manière à ce qu'elle soit bien en évidence.
- 5. NE JAMAIS PASSER SOUS LA PORTE EN MOUVEMENT.
- NE JAMAIS PASSER SOUS UNE PORTE À L'ARRÊT PARTIELLEMENT OUVERTE.
- 7. Le système d'exploitation Aladdin Connect ™ a été conçu pour fonctionner sans surveillance. La porte peut se déplacer de facon inattendue.
- 8. NE PAS installer Aladdin Connect™ sur les ouvreportes de garage fabriqués avant 1993, sans capteurs de sécurité photoélectrique sans contact.
- 9. NE PAS installer sur les portes d'une seule pièce.
- 10. Installez DCM dans un endroit où il peut être vu et entendu tout en se tenant dans l'ouverture de la porte avec la porte en position ouverte.

CONSERVER CES INSTRUCTIONS

WARNING


UNPLUG GARAGE DOOR OPENER PRIOR TO INSTALLING
ALADDIN CONNECT™
Door may operate unexpectedly.

AVERTISSEMENT

DÉBRANCHER L'OUVRE-PORTE DE GARAGE AVANT D'INSTALLER ALADDIN CONNECT™ La porte peut fonctionner de façon inattendue.

In the Home close to Wi-Fi Router:

- 1. Remove mounting bracket from back of DCM. FIG.A,
- 2. Plug Aladdin Connect™ into wall outlet with Power Pack. FIG. B.
- 3. Plug power pack into DCM controller.



NOTE: Customers using control apps from other vendors and NOT using the Aladdin Connect^{TM} app to control this system will need to visit www.GenieCompany.com/AladdinConnect for specific Wi-Fi instructions.

STEP 2

In the Home close to Wi-Fi Router: Download the Aladdin Connect™ app.

- Scan the QR code below or visit www.GenieCompany. com/AladdinConnect to start the setup of the Aladdin Connect™ device.
- 2. Follow the on-screen menus to create an account and program system prior to wiring in the garage.
- 3. At the installation prompt, disconnect power pack and move system to the garage.



Installation Prompt

Scan for app.









Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

In the Garage:

These factors must be determined prior to mounting Aladdin Connect™ (DCM) to the wall or ceiling.

1. Optimal Wi-Fi signal strength.

• If an optimal signal cannot be located within the garage, move the wireless router closer to the garage or install a Wi-Fi range extender (available from most electronic stores)

2. Desired DCM location.

3. Access to 110VAC outlet within 5 feet.

1. Plug Power Pack into wall outlet and DCM near the chosen mounting location.

The WI-FI signal indicator LED should illuminate signaling that the Wi-Fi signal is still in tact.

- A GREEN LED indicates a good Wi-Fi signal.
- A YELLOW LED, indicates a weak signal. Move Aladdin Connect™ to a position that better suits the Wi-Fi signal from the router.
- A RED LED, indicates a lost or faulty signal. Move Aladdin Connect™ to a position that better suits the Wi-Fi signal from the router.
- Once an **optimal** signal and location is obtained, UNPLUG POWER PACK from the DCM and continue to STEP 4.

WARNING

UNPLUG GARAGE DOOR OPENER PRIOR TO INSTALLING ALADDIN CONNECT™

Door may operate unexpectedly.

AVERTISSEMENT

DÉBRANCHER L'OUVRE-PORTE DE GARAGE AVANT D'INSTALLER ALADDIN CONNECT™

La porte peut fonctionner de façon inattendue.

Wi-Fi Signal Indicator










Wire Aladdin Connect™: (Single door install shown)

Aladdin Connect™ will wire directly to the wall control connections at the powerhead or directly to the wall control. New Genie models shown.

- 1. Make sure garage door opener is unplugged.
 - Leave wire spool intact for this part of the install.
- 2. Split provided dual strand wire approximately 2 in. then strip 1/2 in. of insulation. FIG. A.
- 3. Press orange tabs down and insert both wires into connection points for DOOR 1 on the back of the DCM. FIG. B.
- 4. Trim and split the other end of the dual strand wire approximately 2 in. and then strip 1/2 in. of insulation. FIG. A.
- 5. Insert wire into wall control inputs either:
 - (OPTION A) Directly to the garage door opener.
 - OR
 - (OPTION B) To the Back of the wall control.


Button & Connection Detail





Wire Aladdin Connect™: (Continued)

Current model Genie® Brand opener shown.





Mount and Power Aladdin Connect™:

- 1. Using the DCM mounting bracket as a template at the optimal Wi-Fi location. Mark and drill 2-3/32" pilot holes and mount bracket to wall using supplied screws. If mounting to drywall, use anchors provided in kit or if mounting to perforated angle at opener location, use nuts, washers and screws provided.
- 2. Plug power pack into wall outlet. An extended screw is provided to secure power pack to outlet if needed.
- 3. Plug power pack into back of DCM as shown in **STEP 1**.

NOTE: LEDs on DCM will flash momentarily as it reacquires signals.

- 4. Snap DCM onto mounting bracket.
- 5. Route wires and secure with supplied staples.
- 6. Affix the warning placard next to wall control or DCM in plain sight to signify that the door will operate remotely.





MOVING DOOR can cause serious injury or death.
STAND CLEAR!
Door could close automatically.
Do Not stop or stand in doorway
MOUVEMENT PORTE peut causer des blessures graves ou la mont.
SE TENIR À L'ECART DE LA PORTE!
Laports pourst ar refierre automatiguement.
Ne pas arrêter ou debout dans la porte.

Mount DPS Module to Garage Door:


The DPS should be mounted on the **TOP door panel** only. Mount to steel reinforced end stile on the far left or right under the top hinge. DO NOT mount to unreinforced door panel.

- Clean door where DPS will mount.
- Install double sided tape to back of mounting bracket and affix to door.

NOTE: Double sided tape is designed to hold bracket in place temporarily only. Not to be used for permanent mounting.

- 3. Pre-drill 2 3/32 holes. DO NOT drill all the way through door.
- 4. Use included self tapping screws to mount DPS bracket to top door panel end stile.
- 5. Slide DPS down onto mounting bracket. DPS should snap onto bracket.





Complete the Programming:

- 1. Restore power to the garage door opener.
- 2. Follow the on screen prompts to complete the set-up and test the Aladdin Connect™ system.

NOTE: This kit includes one DPS sensor for use with one door only. Additional DPS sensors can be purchased separately from your local Genie retailer. **NOTE:** A white light will flash and an audible beep will sound as an indication that the door is about to move when commanded by the Aladdin Connect $^{\text{TM}}$ or other compatible app(s).

HOW TO ORDER REPAIR PARTS

DEVANCO CANADA

19192 HAY ROAD, UNIT Q SUMMERSTOWN, ON KOC 2E0

TOLL FREE: 855-931-3334 www.devancocanada.com

WHEN ORDERING REPAIR PARTS
PLEASE SUPPLY THE FOLLOWING INFORMATION:

- **✓ PART NUMBER**
- **✓ DESCRIPTION**
- **✓ MODEL NUMBER**



The Aladdin Connect™ system is designed to operate on garage door openers manufactured after 1993 and in compliance with UL325 utilizing non-contact safety devices (photocells).

Only for use on standard sectional garage doors.

DO NOT install Aladdin Connect™ on garage door openers without safety photocells.

DO NOT install Aladdin Connect™ on swing-out or one-piece garage doors.

Install DCM in a location where it can be seen and heard while standing in the door opening with the door in the open position.





FCC/IC Statement:

This device complies with FCC Part 15 rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of this device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de license. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil no doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit acceptor tout brouillage radioélectrique subi, même si

le brouillage est susceptible d'en compromettre le fonctionnement.



Aladdin Connect™ Limited Warranty

GMI Holdings, Inc. d/b/a The Genie Company ("Seller") warrants to the original purchaser of the Genie Aladdin Connect ("Product"), subject to all of the terms and conditions hereof, that the Product and all components thereof will be free from defects in materials and workmanship for a period of One (1) Year, from the date of purchase:

Seller's obligation under this warranty is specifically limited to repairing or replacing, at its option, the Product or any part thereof which is determined by Seller to be defective during the applicable warranty period. Any labor charges are excluded and will be the responsibility of the purchaser.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is made to the original purchaser of the Product only, and is not transferable or assignable. This warranty applies only to Product installed in a residential application. It does not cover any Product installed in commercial or industrial building applications. This warranty does not apply to any unauthorized or improper installation, alteration or repair of the Product, or to any Product or component which has been damaged or deteriorated due to misuse, neglect, accident, failure to provide necessary maintenance, normal wear and tear, or acts of God or any other cause beyond the reasonable control of Seller, and does not cover batteries, missing or damaged parts from clearance or open box sales, repairs or maintenance to door or operator components, or any failure to follow programming instructions or incompatibility with your home router, garage door opener or other electronics.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN TIME TO THE APPLICABLE WARRANTY PERIOD REFLECTED ABOVE. NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE LIMITED WARRANTY PERIOD HAS EXPIRED. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

IN NO EVENT SHALL GMI HOLDINGS, INC. OR ITS PARENT OR AFFILIATES BE RESPONSIBLE FOR, OR LIABLE TO ANYONE FOR, SPECIAL, INDIRECT, COLLATERAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL DAMAGES, even if Seller has been advised of the possibility of such damages. Such excluded damages include, but are not limited to, loss of use, cost of any substitute product, or other similar indirect financial loss. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Claims under this warranty must be made promptly after discovery and within the applicable warranty period. To obtain warranty service, you must contact Genie® customer service, attempt reasonable trouble-shooting measures and provide proof of the date and location of purchase and of your identity as the original purchaser of the Product. Call Genie Customer Service toll free at 1-866-599-4995 to speak with a trained representative. Purchaser must allow Seller a reasonable opportunity to inspect the Product claimed to be defective prior to removal or alteration of its condition. Upon determination by Seller that the Product or any part thereof is defective during the applicable warranty period (which may require purchaser to return the Product to Seller at purchaser's expense), Seller will supply the purchaser with replacement parts or, at its option, a replacement Product (shipping and handling of any replacement Product or parts also at purchaser's expense). Seller may use new or reconditioned parts, or a new or reconditioned Product of the same or similar design.

There are no established informal dispute resolution procedures of the type described in the Magnuson-Moss Warranty Act.