
## P-639T



## Open, Close & Stop Transmitter to Control 9 Doors.

Match dipswitches 1 thru 6 on both transmitter and receiver. Set the 7th and 8th dipswitch in open/close/stop receivers accordingly.

Receiver	Dial Setting	7th Dipswitch on Receiver	8th dipswitch on Receiver
Door 1	1	"+"	"+"
Door 2	2	"+"	"O"
Door 3	3	"+"	‹‹››
Door 4	4	"O"	"+"
Door 5	5	"O"	"O"
Door 6	6	"O"	‹‹››
Door 7	7	۰۰,	" <del>+</del> "
Door 8	8	۰۰,	"O"
Door 9	9	<u>‹‹</u> ››	· <u></u> ;,

<sup>&</sup>quot;Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment"