


# P-8866TC-OCS



**Open, Close & Stop transmitter to control 6 Doors.** Match dipswitches 1, 2, 3, 4, 5 & 8 on both transmitter and receiver. Set the 6th and 7th dipswitch in the open/close/stop receivers accordingly.

Receiver	Slide Switch 1, 2	Slide Switch ABC	6th Dipswitch on Receiver	7th Dipswitch on Receiver
Door 1	1	A	“+”	“+”
Door 2	1	B	“O”	“+”
Door 3	1	C	“—”	“+”
Door 4	2	A	“+”	“O”
Door 5	2	B	“O”	“O”
Door 6	2	C	“—”	“O”